



st@r ink

OURWAY IMAGE CO.,LTD.

www.ourwayink.com





Better Choice More Choices



Continuous Ink Supply System

Auto reset chip, Install once and print forever;
Significant Saving on printing cost;
Environmentally Protective, no waste ink;
Smooth ink flow for better printing quality;
Easy installation and less maintenance for printers.

Continuous Ink Supply System



Part No	OEM Model	Color	Ink Volume (ml)	Compatible for printers
CANON				
CS-CP5BK/ CC8C/CC8M/CC8Y	Clss PGI5BK/ CLI-8C/CLI-8M/CLI-8Y	B/C/M/Y	90	PIXMA Ip3300/Ix4000/Ix5000
CS-CP5BK/CC8BK/ CC8C/CC8M/CC8Y	Clss PGI5BK/CLI-8BK/ CLI-8C/CLI-8M/CLI-8Y	B/B/C/M/Y	90	PIXMA series: Ip4200/Ip4300/Ip4500/Ip5200/Ip5200R/Ip5300 All-in-one series: mp500/mp510/mp530/mp600/mp600r/mp800/ mp800r/mp810/mp830/mp950/mp960
CS-CC-8B/8C/8M/ 8Y/8PC/8PM	Clss CLI-8B/8C/8M/ 8Y/8PC/8PM	B/C/M/Y/PC/PM	90	Canon PIXMA IP6600D/IP6700D
CS-CP5BK/CC8BK/8C/ 8M/8Y/8PC/8PM	Clss PGI-5BK/CLI-8BK/ 8C/8M/8Y/8PC/8PM	B/B/C/M/Y/PC/PM	90	Canon PIXMA MP950/MP960/MP970
CS-CC8BK/8C/8M/ 8Y/8PC/8PM/8G/8R	Clss CLI-8BK/8C/8M/ 8Y/8PC/8PM/8G/8R	B/C/M/Y/PC/PM/G/R	90	Canon Pro9000
CS-CB6B/3eB/ 6C/6M/6Y	Clss BCI-6B/3eB/ 6C/6M/6Y	B/B/C/M/Y/	90	PIXMA IP4000/IP5000/IP8500/IP6000D/MP750/MP760/MP780/I860/I865
CS-CB6B/6C/6M/ 6Y/6PC/6PM	Clss BCI-6B/6C/6M/ 6Y/6PC/6PM	B/C/M/Y/PC/PM	90	PIXMA IP6000D/I900D/I905D/I950/I960/I965/I9100/S800/S820/S820D/ S830D/S900/S9000/BJC-8200 Photo
CS-CB6BK/6C/6M/ 6Y/6PM/6PC/6R	Clss BCI-6BK/6C/6M/ 6Y/6PM/6PC/6R	B/C/M/Y/PC/PM/R	90	I990
CS-CB6B/6C/6M/ 6Y/6PC/6PM/6G/6R	Clss BCI-6B/6C/6M/ 6Y/6PC/6PM/6G/6R	B/C/M/Y/PC/PM/G/R	90	Canon I9900/I9950/IP8500/
CS-CB3eBK/3eC/ 3eM/3eY	Clss BCI-3eBK/3eC/ 3eM/3eY	B/C/M/Y	90	I550/I850/I6100/I6500/S520/S600/S750/ S6300/MP700/S530D/MPC400/MPC600F
CS-CB3eB/6C/6M/6Y	Clss BCI-3eB/6C/6M/6Y	B/C/M/Y	90	I560/PIXMA IP3000
CS-CB24B/CB24C	Clss BCI-24B/BCI-24C	B/C/M/Y	90	PIXMA IP1000/IP1500/IP2000/MP110/MP130/PIXUSMP375R/I250/ I255/I320/I350/I355/I450/I450x/I455/I470D/I475D/S200/S200x/ S200SP/S200SPx/S300/S330 Photo /Smart Base MP360/370/390/ MPC190/I90S/200/200 Photo /360/390/XNUI 320
CS-PG-40B/41C	Clss PG-40B/41C	B/C/M/Y	90	PIXMA IP1200/IP1300/IP1600/IP1700/IP2200/IP6210D/IP6220D/IP6310D/ All-In-One MP150/MP160/MP170/MP180/MP450/MP460
CS-CP225/226	Clss PGI225/226	B/B/C/M/Y	/	PIXMA Ip4810/Ip4820/Ip4830/Ip4840/Ip4850/Ip4870/Ip4881
CS-CP325/326	Clss GPI325/326	B/B/C/M/Y	/	PIXMA Ip4810/Ip4820/Ip4830/Ip4840/Ip4850/Ip4870/Ip4880
CS-CP425/426	Clss PGI425/426	B/B/C/M/Y	/	PIXMA Ip3600/Ip3680/Ip4600/Ip4680/Ip4700
CS-CP525/526	Clss PGI525/526	B/B/C/M/Y	/	PIXMA Ip3300/Ix4000/Ix5000
CS-CP725/726	Clss PGI725/726	B/B/C/M/Y	/	PIXMA series: Ip4200/Ip4300/Ip4500/Ip5200/Ip5200R/Ip5300 All-in-one series: mp500/mp510/mp530/mp600/mp600r/mp800/ mp800r/mp810/mp830/mp950/mp960
CS-CP825/826	Clss PGI825/826	B/B/C/M/Y	/	Canon PIXMA IP6600D/IP6700D
CS-CP520/CC521	Clss PGI520/CLI521	B/B/C/M/Y	/	Canon PIXMA MP950/MP960/MP970
CS-CP820/CC821	Clss PGI820/CLI821	B/B/C/M/Y	/	Canon Pro9000
CS-CP220/CC-221	Clss PGI220/CLI-221	B/B/C/M/Y	/	PIXMA IP4000/IP5000/IP8500/IP6000D/MP750/MP760/MP780/I860/I865
CS-CB320/321	Clss BCI-320/321	B/B/C/M/Y	/	PIXMA IP6000D/I900D/I905D/I950/I960/I965/I9100/S800/S820/S820D/ S830D/S900/S9000/BJC-8200 Photo
EPSON				
CS-ET1281-1284	Clss T1281-T1284	B/C/M/Y	90	S22/SX120/SX125
CS-ET1281-1284	Clss T1281-T1284	B/C/M/Y	90	SX420/SX425
CS-ET1231,1332-1334	Clss T1231,T1332-T1334	B/C/M/Y	90	T22/TX120
CS-ET1331-1334	Clss T1331-T1334	B/C/M/Y	90	TX320/TX420
CS-ET1351,1332-1334	Clss T1351,T1332-T1334	B/C/M/Y	90	T25/TX125
CS-ET1401-1404	Clss T1401-T1404	B/C/M/Y	90	TX560W/TX620W
CS-ET1251-1254	Clss T1251-T1254	B/C/M/Y	90	NX125/NX127/NX420/NX625
CS-ET1411-1414	Clss T1411-T1414	B/C/M/Y	90	ME32/ME320

Continuous Ink Supply System



Part No	OEM Model	Color	Ink Volume (ml)	Compatible for printers
CS-ET731N-734N	Ciss T0731N-T0734N	B/C/M/Y	90	Epson T10/T11/T20/T20E/TX200/TX100/TX101/TX105/TX110/TX111/TX117/TX119/TX200/TX210/TX410/TX300F/TX209/TX400/TX409/TX419
CS-ET731N-734N	Ciss T0731N-T0734N	B/B/C/M/Y	90	Epson T30
CS-ET115/115/732-4N	Ciss T115/T115/T0732-4N	B/B/C/M/Y	90	Epson T33
CS-ET731HN,1032-1034	Ciss T0731HN,T1032-T1034	B/B/C/M/Y	90	Epson T1100/TX510
CS-ET115I,1032-1034	Ciss T115I,T1032-T1034	B/B/C/M/Y	90	Epson T1110/TX515
CS-ET1031-1034	Ciss T1031-T1034	B/C/M/Y	90	Epson T40w/TX550/TX600
CS-ET117,732N-734N	Ciss T117,T0732N-T0734N	B/C/M/Y	90	Epson T23/T24/TX105/TX115
CS-ET731/2/3/4	Ciss T0731/2/3/4	B/C/M/Y	90	C90/C92/C79/CX3900
CS-ET731/2/3/4	Ciss T0731/2/3/4	B/C/M/Y	90	CX4900/CX5900/CX4905/CX5500/CX5600/CX5505/CX7300/CX8300
CS-ET731/731/2/3/4	Ciss T0731/T0731/2/3/4	B/B/C/M/Y	90	Stylus C110
CS-ET611/2/3/4	Ciss T0611/2/3/4	B/C/M/Y	90	Stylus D68/D88/DX3800/DX3850/DX4200/DX4250/DX4800/DX4850
CS-ET711/2/3/4 or CS-ET891-0894 SX100	Ciss T0711/2/3/4 or Ciss T0891-0894 SX100	B/C/M/Y	90	Epson Stylus S20/SX100/SX105/SX200/SX205/SX209/SX400/SX405/SX600FW/B40W/BX300F/BX3450F/BX600FW
CS-ET711/2/3/4	Ciss T0711/2/3/4	B/C/M/Y	90	D92/D78/DX4050/DX4400/DX5000/DX5050/DX6000/DX7450/DX8450
CS-ET711/711/2/3/4	Ciss T0711/T0711/2/3/4	B/B/C/M/Y	90	Stylus D120
CS-ET711H,712-714	Ciss T0711H,T0712-T0714	B/C/M/Y	90	Epson Stylus BX600/BX625/BX610/BX525/BX310
CS-ET711H, 1002-1004	Ciss T0711H, T1002-T1004	B/B/C/M/Y	90	B1100/B1110
CS-ET801/2/3/4/5/6	Ciss T0801/2/3/T4/5/6	B/C/M/Y/LC/LM	90	Epson PX700/PX800
CS-ET801/2/3/4/5/6	Ciss T0801/2/3/T4/5/6	B/C/M/Y/LC/LM	90	Stylus RX560/RX585/RX685/R265/R285/R360/
CS-ET691/2/3/4NX100	Ciss T0691/2/3/4NX100	B/C/M/Y	90	Epson Stylus NX100/NX200/NX300/NX400/Workforce30/40/500/600
CS-ET691-694	Ciss T0691-T0694	B/C/M/Y	90	CX5000/CX6000/CX7400/CX8400/CX9400F
CS-ET691-694	Ciss T0691-T0694	B/B/C/M/Y	90	Workforce 30/Workforce 1100
CS-ET691/691/2/3/4	Ciss T0691/T0691/2/3/4	B/B/C/M/Y	90	Stylus C120
CS-ET781-786/771-776	Ciss T0781-T0786/T0771-T0776	B/C/M/Y/LC/LM	90	Stylus R260/R280/R380/RX580/RX595/RX680
CS-ET781-786	Ciss T0781-T0786	B/C/M/Y/LC/LM	90	Artisan 50
CS-ET881-884	Ciss T0881-T0884	B/C/M/Y	90	CX4400/CX7400
CS-ET821-826/811-816	Ciss T0821-T0826/T0811-T0816	B/C/M/Y/LC/LM	90	Stylus Photo R270/R290/R390/RX590/RX610/RX690
CS-ET811N-816N	Ciss T0811N-T0816N	B/C/M/Y/LC/LM	90	TX700W/TX800FW/T50/T59
CS-ET811-816	Ciss T0811-T0816	B/C/M/Y/LC/LM	90	Photo 1410
CS-ET981/992/3/4/5/6	Ciss T0981/T0992/3/4/5/6	B/C/M/Y/LC/LM	90	Epson Artisan 600/700/800/810
CS-ET791/2/3/4/5/6	Ciss T0791/2/3/T4/5/6	B/C/M/Y/LC/LM	90	Epson 1400
CS-ET870-874,877-879	Ciss T0870-T0874,T0877-T0879	B/C/M/Y/MB/R/OR/GO	90	R1900
CS-ET961/2/3/4/5/6/7/9	Ciss T0961/2/3/4/5/6/7/9	B/C/M/Y/LC/LN/LB/LB	90	R2880(With Photo black instead of matte black)
CS-ET921/2/3/4N	Ciss T0921/2/3/4N	B/C/M/Y	90	Stylus T26/TX106/TX109/TX117
CS-ET921/2/3/4	Ciss T0921/2/3/4	B/C/M/Y	90	C91/CX4300
CS-ET851/2/3/4/5/6	Ciss T0851/2/3/T4/5/6	B/C/M/Y/LC/LM	90	Epson 1390
CS-ET851N-856N	Ciss T0851N-T0856N	B/C/M/Y/LC/LM	90	Epson T60
CS-ET751/2/3/4	Ciss T0751/2/3/4	B/C/M/Y	90	Stylus C59/CX2900/CX2905
CS-ET761/2/3/4	Ciss T0761/2/3/4	B/C/M/Y	90	Stylus C58/CX2800/Me200/Me2
CS-ET07/08	Ciss T007/T008	B/C/M/Y/LC/LM	90	Stylus Photo 780/785EPX/790/825/870/875DC/875DCS/890/895/915
CS-ET07/09	Ciss T007/T009	B/C/M/Y/LC/LM	90	Stylus Photo 900/1270/1280/1290/1290S

Continuous Ink Supply System



Part No	OEM Model	Color	Ink Volume (ml)	Compatible for printers
CS-ET13/14	Ciss T013/T014	B/C/M/Y	90	Stylus C20/C20SX/C20UX/C40/C40S/C40SX/C40UX/ Stylus Color 480/480SX/480SXU/580
CS-ET17/18	Ciss T017/T018	B/C/M/Y	90	Stylus Color 680/777/777i/Epson 1000ICS
CS-ET19/20	Ciss T019/T020	B/C/M/Y	90	Epson Stylus Color 880/880i
CS-ET26/27	Ciss T026/T027	B/C/M/Y/LC/LM	90	Stylus Photo 810/820/830/830U/925/935
CS-ET28/29	Ciss T028/T029	B/C/M/Y	90	Stylus C60/C61/CX3100
CS-ET38/39	Ciss T038/T039	B/C/M/Y	90	Stylus C41/C41UX/C43UX/SX/C45/CX1500/CX1500V
CS-ET36/37	Ciss T036/T037	B/C/M/Y	90	Stylus C42UX/C44UX/C46
CS-ET40/41	Ciss T040/T041	B/C/M/Y	90	Stylus C62/CX3200
CS-ET57/58	Ciss T057/T058	B/C/M/Y	90	ME1/ME100
CS-ET66/67	Ciss T066/T067	B/C/M/Y	90	C48
CS-ES187/S193	Ciss S020187/S020193	B/C/M/Y/LC/LM	90	Photo EX3/EX2/EX/720/750
CS-ES093/S110	Ciss S020093/S020110	B/C/M/Y/LC/LM	90	Photo 750/720/710/700
CS-ES191/S187	Ciss S020191/S020187	B/C/M/Y/LC/LM	90	Stylus Color 440/460/640/660/670
CS-ES189/S191	Ciss S020189/S020191	B/C/M/Y/LC/LM	90	740/760/860/1160
CS-ES089/S108	Ciss S020089/S020108	B/C/M/Y/LC/LM	90	800/850/1520
CS-ET321/2/3/4	Ciss T0321/2/3/4	B//M/Y	90	Stylus C70/C80/C80N/C80WN
CS-ET321/422/3/4	Ciss T0321/T0422/3/4	B//M/Y	90	Stylus C82/C82N/C82WN/CX5100/CX5200/CX5300/CX5400
CS-ET331/2/3/4/5/6/7	Ciss T0331/2/3/4/5/6/7	B/LB/C/M/Y/LC/LM	90	Stylus Photo 950/960
CS-ET341/2/3/4/5/6/7	Ciss T0341/2/3/4/5/6/7	B/LB/C/M/Y/LC/LM	90	Stylus Photo 2100/2200
CS-ET441/2/3/4	Ciss T0441/2/3/4	B/C/M/Y	90	Stylus C64/C66/C84/C84N/C84WN/C86/CX3600/CX3650/CX4600/ CX6400/CX6600
CS-ET461/472/3/4	Ciss T0461/T0472/3/4	B/C/M/Y	90	Stylus C63/C65/C83/C85/CX3500/CX4500/CX6500
CS-ET481-486R200	Ciss T0481-T0486R200	B/C/M/Y/LC/LM	90	R200/R300
CS-ET481-486R220	Ciss T0481-T0486R220	B/C/M/Y/LC/LM	90	R220/R320/RX500/RX600
CS-ET491-496R210	Ciss T0491-T0496R210	B/C/M/Y/LC/LM	90	R210/R310/R350/RX510
CS-ET491-496R230	Ciss T0491-T0496R230	B/C/M/Y/LC/LM	90	R230
CS-ET551/2/3/4	Ciss T0551/2/3/4	B/C/M/Y	90	Stylus Photo RX420/RX425/RX520/R240/R245
CS-ET561/2/3/4	Ciss T0561/2/3/4	B/C/M/Y	90	Stylus Photo RX430/R250/RX530
CS-ET5591-5596	Ciss T5591-T5596	B/C/M/Y/LC/LM	90	RX700
CS-ET5570	Ciss T5570	B/C/M/Y	90	Picture Mate 500
CS-ET540/1/2/3/4/6/7/8	Ciss T0540/1/2/3/4/6/7/8	MB/PB/C/M/Y/G/B/GO	90	Stylus Photo R800/R1800
CS-ET591/2/3/4/5/6/7/9	Ciss T0591/2/3/4/5/6/7/9	BK/MB/C/M/Y/LC/LM/LB/LB	90	Stylus Photo R2400 (With Photo black instead of matte black)
CS-ET601/2/3/4	Ciss T0601/2/3/4	B/C/M/Y	90	Stylus C68/C88/CX3800/CX3810/CX4200/CX4800/CX5800F/CX7800
CS-ET631/2/3/4	Ciss T0631/2/3/4	B/C/M/Y	90	Stylus C67/C87/CX3700/CX4100/CX4700
CS-ET1381, 1332/3/4	Ciss T1381, T1332/3/4	B/C/M/Y	90	Epson T420W

Brother

CS-LC39	Ciss LC39/LC985	B/C/M/Y	90	DCP-J125/DCP-J315W/DCP-J515W/MFC-J220/MFC-J265W/MFC-J410/ MFC-J415W
CS-LC11	Ciss LC11/LC16/LC38/LC61/LC67/LC980/LC1100	B/C/M/Y	90	MFC-5890CN/MFC-6490W/MFC250C/MFC-290C/MFC-490CW/ DCP-145/MFC-490CN/MFC-930/CDWN/MFC-670CD/CDW/ MFC-5490CN/MFC-6490W/DCP-165/DCP-185/DCP-6690CW/ DCP-165C/DPC-385C/DPC-535CN/DCP-585CW
CS-LC10	Ciss LC10/LC51/LC57/LC960/LC1000	B/C/M/Y	90	DCP-130C/330C/540CN/750CW/MFC-240CN/440CN/660CN/665CW

Continuous Ink Supply System



Part No	OEM Model	Color	Ink Volume (ml)	Compatible for printers
CS-LC41	Ciss LC41/LC47/LC900/LC950	B/C/M/Y	90	DCP-110C/115C/120C/310CN/315C/MFC-210C/215C/410CN/420CN/425CN/610CLN/610CLWN/615CL/620CN/620CLN/640CW/830CLN/830CLWN/3240C/3340CN/5440CN/5840CN

HP

CS-H10(C4844a) H11(C4836a/37a/38a)	Ciss HP10(C4844a) HP11(C4836a/37a/38a)	B/C/M/Y	90	HP Design jet 100/110/70/Business Ink jet 1000/1100d/1200d/2300/2800/Deskjet2000 series/Office jet 9110/9120/9130
CS-H10(C4844a) H82(C4911a/12a/13a)	Ciss HP10(C4844a) HP82(C4911a/12a/13a)	B/C/M/Y	90	HP Design jet 500/500ps/800/800ps/815mfp/copiercc800ps
CS-H10(C4844a) H12(C4804a/05a/06a)	Ciss HP10(C4844a) HP12(C4804a/05a/06a)	B/C/M/Y	90	HP Business Ink jet 3000/3000n/3000dn
CS-H10(C4844a) H10(C4841a/42a/43a)	Ciss HP10(C4844a) HP10(C4841a/42a/43a)	B/C/M/Y	90	HP Deskjet 2500/2000C/Professional series
CS-H88(C9385AN) H88(C9386AN/87AN/88AN)	Ciss HP88(C9385AN) HP88(C9386AN/87AN/88AN)	B/C/M/Y	90	HP Officejet Pro K550/K850/K550 dtwn
CS-C9385/C9386/C9387/C9388 C4936A/C4937A/C4938A/ C4939A	Ciss C9385/C9386/C9387/C9388 C4936A/C4937A/C4938A/ C4939A	B/C/M/Y	90	HP Officejet Pro K5300/K5400/L7580/L7780/L7590/L7380/L7660/L8600
CS-H84(C5016a) H85(C9425a/26a/27a/28a/29a)	Ciss HP84(C5016a) HP85(C9425a/26a/27a/28a/29a)	B/C/M/Y	90	HP Designjet 130/30/90 series
CS-H11(C4836a/37a) H82(C4913a) H84(C5016a/17a/18a)	Ciss HP11(C4836a/37a) HP82(C4913a) HP84(C5016a/17a/18a)	B/C/M/Y	90	HP Designjet 10ps/20ps/50ps/HP Designjet 120 series
CS-H363(C721EE/C8771EE/ C8772EE/C8773EE/C8774EE/ C8775EE)	Ciss HP363(C721EE/C8771EE/ C8772EE/C8773EE/C8774EE/ C8775EE)	B/C/M/Y/LC/LM	90	HP Photosmart 3108/3308/8238/8250 Ireland/UK/European Mainland
CS-H02/177(C721WA,C877 1WA,C8772WA,C8773WA, C8774WA,C8775WA)	Ciss HP02/177(C721WA,C8771WA,C8772WA,C8773WA,C8774WA,C8775WA)	B/C/M/Y/LC/LM	90	HP Photosmart 3110/3310/8250/8230 U.S./CANADA./SOUTHEAST/ASIA
CS-H72(C9370/1/2/3/4a) C9403a	Ciss HP72(C9370/1/2/3/4a) C9403a	PB/MB/C/M/Y/GY	90	HP Designjet T610/T1100/T1120/T1200/T620/T770
CS-H70	Ciss HP70	B/C/M/Y	90	HP Designjet Z2100
CS-H38 (C9412AC9419A)	Ciss HP38 (C9412A-C9419A)	PB/MB/C/M/Y/LC/ LM/LB	90	HP B9180
CS-H940	Ciss HP940	B/C/M/Y	90	HP PRO 8000/8500
CS-H920	Ciss HP920	B/C/M/Y	90	HP PRO 6500
CS-H178/364/564/862	Ciss HP178/364/564/862	B/B/C/M/Y	90	HP D5460/D7560/D6380

universal

CS-100 ML 4C Ink Tank (universal CISS with Ink)	Ciss 100 ML 4C Ink Tank (universal CISS with Ink)	B/C/M/Y	100	
--	--	---------	-----	--



Add: No. 291 People's West Road, Xiangzhou,
Zhuhai, Guangdong, China
Tel: (86) 756-2629616 2628620
Fax: (86) 756-2622492
E-mail: promo2@ourwayink.com
<http://www.ourwayink.com>

All brand names & trademarks are the properties of their respective owners, they are referred to here for descriptive purposes only.