



铜板纸墨水

Art Paper Ink

FOR EPSON

打印机/Printer:EPSON T50 打印纸张/Midia Tipe: copperplate paper打印模式/Mode: BEST PHOTO



Printer:EPSON T50
Midia Tipe: Epson Premium Glossy
Ink:cheng jie copperplate Ink
Print Quality: BEST PHOTO
Software:Win XP/CoreDAW X4 Date:2012-10-31



Printer:EPSON T50
Midia Tipe: Epson Premium Glossy
Ink:cheng jie copperplate Ink
Print Quality: BEST PHOTO
Software:Win XP/CoreDAW X4 Date:2012-10-31



铜板纸墨水

Art Paper Ink

FOR EPSON

打印机/Printer:EPSON T50 打印纸张/Midia Tipe:copperplate paper打印模式/Mode: BEST PHOT0



Printer: Epson T50
Midia Tipe: Epson Premium Glossy
Ink: Completer 1 copperplate ink
Print Quality: Best Photo
Software: Win XP/CoreDAW X4 Date: 2012-11-01



Printer: Epson T50
Midia Tipe: Epson Premium Glossy
Ink: Completer 1 copperplate ink
Print Quality: Best Photo
Software: Win XP/CoreDAW X4 Date: 2012-11-01